Operational Manual Installation Manual

Air-to-water Heat Pump SERIE



GSH-120IRA-3 GSH-120ERA-3 GSH-140IRA-3 GSH-140ERA-3 GSH-160IRA-3 GSH-160ERA-3



Contents

1. Instruction to Users	2
2. Safety Considerations	3
3. Diagram of the Operating Principle	6
4. Operating Principle of the Unit	6
5. Model Line-Up	9
6. Installation Example	10
7. Main components	13
8. Installation Guideline of the unit	16
9. Installation of Indoor Unit	19
10. Connection of pipeline	26
11. Remote Air Temperature Sensor	29
12. Thermostat	31
13. 2-Way Valve	32
14. 3-Way Valve	33
15. Gate-controller	34
16 Filling of Refrigerant	34
17. Installation of Insulated Water Tank	35
18 Wring Diagram	40
19. Debugging Operation of Unit	52
20. Daily Operation and Maintenance	54
21. Parameter Lists	57

1. Instruction to Users

Thank you for choosing our Air to water Heat Pump. Please read this manual carefully before installation and use the unit correctly according to the following procedure.

- After receipt of the unit, check it for appearance, unit model compared with your desire and attachments.
- For proper installation and future maintenance please read this Instruction and keep it carefully.
- Design and installation work of the unit must be performed by authorized personnel according to applicable laws and regulations and this Instruction.
- After installation work, the unit can not be energized unless there is not any problem in check.
- Ensure periodical clean and maintenance of the unit after normal operation of the unit for longer life and reliable operation.
- For improvement of products, there should be not additional notice of amendment of the contents.
- This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
- Children should be supervised to ensure that they do not play with the appliance.





This product must not be disposed together with the domestic waste. This product has to be disposed at an authorized place for recycling of electrical and electronic appliances.

2. Safety Considerations

Γ

Please read the following contents carefully before operating.						
WARNING						
 ★ Once abnormality like burning smell occurs, please cut off the power supply immediately and then contact with service center. If the abnormality still exists, the unit may be damaged and electric shock or fire may result 	★ Don't operate the unit with wet hand. Image: Constraint of the constraint of th	★ Before installation, please see if the voltage of local place accords with that on nameplate of unit and capacity of power supply, power cord or socket is suitable for input power of this unit.				
★ Special circuit must be adopted for power supply to prevent fire.	★ Be sure to pull out the power plug and drain the indoor unit and water tank when unit is not in use for a long time.	★ Never damage the electric wire or use the one which is not specified.				
Do not use octopus multipurpose plug or mobile terminal board for wire connection.	Otherwise, the accumulated dust may cause overheating, fire or freeze of water tank or coaxial heater exchanger in winter.	Otherwise, it may cause overheating or fire.				

 ★ Before cleaning please cut off the power supply. Image: Constant of the power supply. Image: Constant of the power supply. Image: Constant of the power supply. 	★ The power supply must adopt special circuit with leakage switch and enough capacity.	★ User can not change power cord socket without prior consent. Wiring working must be done by professionals. Ensure good earthing and don't change earthing mode of unit.
★ Earthing: the unit must be earthed reliably ! The earthing wire should connect with special device of buildings. If not, please ask the qualified personnel to install. Furthermore, don't connect earth wire to gas pipe, water pipe, drainage pipe or any other improper places which professional does not recognize	★ Never insert any foreign matter into uint to avoid damage. And never insert your hands into the air outlet of outdoor unit.	 ★ Don't attempt to repair the unit by yourself. Improper repair may cause electric shock or fire, so you should contact the service center to repair.
★ Don't step on the top of the unit or place anything on it.	★ Never block the air inlet and outlet of unit.	★ Keep pressurized spray, gas holder and so on away from the unit above 1m.
There is the danger of fall of things or people.	It may reduce efficiency or cause stop of the unit and even fire.	It may cause fire or explosion.

\star Please note whether the \star unit should be installed at water in water tank installation stand is firm the place with good ventilation power the unit on to	k, never
installation stand is firm the place with good ventilation power the unit on to	RU10
	run.
enough or not. to save energy.	
If damaged, it may cause fall of the unit and injury of people.	



- 1. Before installation, please check if the adopted power is accordance with that listed on nameplate, and check the safety of power.
- 2. Before using, please check and confirm if wires and water pipes are connected correctly to avid water leakage, electric shock or fire etc.
- 3. Don't operate the unit with wet hand, and don't allow children to operate the unit.
- 4. The On/off in the instruction is for the operation to on and off button of PCB for users; cut off power means to stop supplying power to the unit.
- 5. Don't directly expose the unit under the corrosive ambient with water or dampness.
- 6. Don't operate the unit without water in water tank .The air outlet/inlet of unit can not be blocked by other objects.
- 7. The water in unit and pipeline should be discharged if the unit is not in use, to prevent the water tank, pipe line and water pump from frost-cracking.
- 8. Never press the button with sharp objects to protect manual controller. Never use other wires instead of special communication line of the unit to protect control elements. Never clean the manual controller with benzene, thinner or chemical cloth to avoid fading of surface and failure of elements. Clean the unit with the cloth soaked in neutral eradicator .Slightly clean the display screen and connecting parts to avoid fading.
- 9. The power cord must be separated with the communication line.

If there is any question, please contact with local dealer, authorized service center, agencies or our company directly.

3. Diagram of the Operating Principle



1	compressor	10	electric heater	19 expansion tank
2	four-way valve	11	flow switch	20 safety valve
3	finned coil exchanger	12	3-way valve	R1T plate outlet temperature sensor
4	fan motor	13	2-way valve	R2T Liquid line temperature sensor
5	filter	14	by-pass valve	R3T gas line temperature sensor
6	electronic expansion valve	15	under-floor heating	R4T returning water temperature sensor
7	plate heat exchanger	16	radiator	R5T leaving water temperature sensor
8	pump	17	other thermal system	R6T water tank temperature sensor 1
9	air-vent valve	18	water tank	R7T water tank temperature sensor 2

4. Operating Principle of the Unit

DC Inverter Air to Water Heat Pump is composed of outdoor unit, indoor unit and internal-fan coil water tank. Operation functions:

- 1. Cooling;
- 2. Heating;
- 3. Water heating;
- 4. Cooling +water heating;
- 5. Heating+ water heating;
- 6. Emergency mode;
- 7. Quick water heating;
- 8. Holiday mode;
- 9. Forced Operation Mode;
- 10. Silent mode;
- 11. Disinfection mode;
- 12. Weather-dependent Operation;

Cooling: in cooling mode: the refrigerant is condensed in the outdoor unit and evaporated in the indoor unit. Via the heat exchange with water in the indoor unit, the



CASE 2: connecting Sanitary Water Tank

- 1. In this case, three-way valve should be installed and should be complied with installation of this manual;
- 2. Sanitary water tank should be equipped with internal electric heater to to secure enough heat energy in the very cold days;

temperature of water decrease and it releases heat while the refrigerant absorbs heat and evaporates. With the help of wired controller, the outflow temperature can meet the user's requirement. Through the control of valve, the low-temperature water in the system is connected with indoor fan coil and underground pipe, and exchanges heat with the indoor air so that the indoor temperature decreases to the required range.

Heating: in heating mode: the refrigerant evaporates in the outdoor unit and is condensed in the indoor unit. Via the heat exchange with water in the indoor unit, the water absorbs heat and its temperature increase while the refrigerant releases heat and is condensed. With the help of wired controller, the outflow temperature can meet the user's requirement. Through the control of valve, the high-temperature water in the system is connected with indoor fan coil and underground pipe, and exchanges heat with the indoor air so that the indoor temperature increases to the required range;

Water heating: in water heating mode, the refrigerant evaporates in the outdoor unit and is condensed in the indoor unit. Via the heat exchange with water in the indoor unit, the water absorbs heat and its temperature increase while the refrigerant releases heat and is condensed. With the help of wired controller, the outflow temperature can meet the user's requirement. Through the control of valve, the high-temperature water in the system is connected with the coil pipe of bearing water tank, and exchanges heat with the water in the water tank so that the temperature of water tank increases to the required range;

Cooling +water heating: when cooling mode exists together with the water heating mode, the user can set the priority of these two modes based on the needs. The default priority is heat pump. That is under the default setting, if cooling mode exists together with the water heating mode, the heat pump gives priority to cooling. In that case, water heating can only realized with e-heater of the water tank. Inversely, the heat pump gives priority to water heating and switches to cooling after finishing water heating;

Heating+ water heating: when heating mode exists together with the water heating mode, the user can set the priority of these two modes based on the needs. The default priority is heat pump. That is under the default setting, if heating mode exists together with the water heating mode, the heat pump gives priority to heating. In that case, water heating can only realized with e-heater of the water tank. Inversely, the heat pump gives priority to water heating and switches to heating after finishing water heating;

Emergency mode: this mode is only available for heating and water heating. When the outdoor unit stops due to malfunction, enter the corresponding emergency mode; as to heating mode, after entering the emergency mode, heating can only be realized through e-heater of the indoor unit. When the setting outflow temperature or indoor temperature is reached, the e-heater of indoor unit will stop running; as to water heating mode, the e-heater or water tank is reached, the e-heater will stop running;

Quick water heating: in quick water heating mode, the unit runs according to the water heating control of heat pump and the e-heater of water tank runs at the same time;

Forced Operation Mode: this mode is only used for refrigerant recovery and debugging for the unit;

Holiday mode: this mode is only available for heating mode. This mode is set to keep indoor temperature or leaving water temperature in a certain range, so as to prevent water system of the unit from freezing or protect certain indoor articles from freezing damage. When the outdoor unit stops due to malfunction, the two e-heaters of the unit will run.

Disinfection mode: in this mode, the water heating system can be disinfected. When starting up the disinfection function and setting corresponding time to meet the requirement of disinfection mode, the function will start. After the setting temperature is reached, this mode will terminate.

Weather-dependent Operation: this mode is only available for space heating. In Weather-dependent mode, the setting value (remote room air temperature or leaving water temperature) is detected and controlled automatically when the outdoor air temperature is changed.

Silent mode: Silent mode is available in cooling, heating and water heating mode. In silent mode, the outdoor unit will reduce the running noise via automatic control.

5. Model Line-Up

Madal Nama	Ca	Bower cupply	
Model Name	Heating, KW	Cooling, KW	Power supply
GSH-160IRA GSH-160ERA	16 ¹	15.5 ²	
GSH-140IRA GSH-140ERA	14	15	
GSH-120IRA GSH-120ERA	12	14	220-240V
GSH-100IRA GSH-100ERA	10	10.5	1Ph~
GSH-80IRA GSH-80ERA	8.5	9.0	50Hz
GSH-60IRA GSH-60ERA	6.2	5.5	
GSH-160IRA-3 GSH-160ERA-3	15 ¹	15.5 ²	380-415V
GSH-140IRA-3 GSH-140ERA-3	14	15	$3Ph\sim$
GSH-120IRA-3 GSH-120ERA-3	12	14	50112

Note:

¹ Capacities and power inputs are based on the following conditions: Indoor Water Temperature 30°C/35°C, Outdoor Air Temperature 7°CDB/6°CWB;
 ² Capacities and power inputs are based on the following conditions:

Indoor Water Temperature 23°C/18°C, Outdoor Air Temperature 35°CDB/24°CWB

6. Installation Example

CASE 1: connecting Under-floor coil for heating and cooling



- 1. Type of thermostat and specification should be complied with installation of this manual;
- 2. By pass valve must be installed to secure enough water flow rate, and by pass valve should be installed at the collector;

CASE 3 : connecting Sanitary Water Tank and Heat Emitters for heating and Cooling;



Two-way valve is very important to prevent dew condensation on the floor and Radiator while cooling mode.

7. Main components

7.1 Indoor units	GSH-60IRA GSH-80IRA
	GSH-100IRA
	GSH-120IRA
	GSH-140IRA
	COLL 1COLD A

GSH-120IRA-3 GSH-140IRA-3 GSH-160IRA-3



7.2. Outdoor unit

7.2.1 GSH-60ERA, GSH-80ERA, GSH-100ERA



7.2.2 GSH-120ERA, GSH-140ERA, GSH-160ERA GSH-120ERA-3, GSH-140ERA-3, GSH-160ERA-3



External



8.Installation Guideline of the unit

8.1 Instruction to installation

- + The installation of unit must be in accordance with national and local safety codes.
- Installation quality will directly affect the normal use of air conditioner unit. The user is prohibited from installation by himself. Please contact your dealer after buying this machine. Professional installation workers will provide installation and test services according to installation manual.
- Do not connect to power until all installation work is completed.

8.2 Installation of Outdoor Unit

8.2.1 Select Installation Location of Outdoor Unit

- Outdoor unit must be installed on a firm and solid support.
- Outdoor unit shall be installed close to the indoor unit, hence to minimize the length and bends of cooling pipe.
- Avoid placing the outdoor unit under window or between two constructions, hence to prevent normal operating noise from entering the room.
- Air flow at inlet and outlet shall not be blocked.
- Install at a well-ventilated place, so that the machine can absorb and discharge sufficient air.
- Do not install at a place where flammable or explosive goods exist or a place subject to severe dust, salty fog and polluted air.

8.2.2 Outline dimension of outdoor unit GSH-60ERA, GSH-80ERA, GSH-100ERA







GSH-120ERA, GSH-140ERA, GSH-160ERA GSH-120ERA-3, GSH-140ERA-3, GSH-160ERA-3





Descrip	ption		Unit: inch			
No	Name		Remarks			
		2/9	GSH-80,100,120,140,160IRA/ERA			
1	Liquid-side Service Valve	5/8	GSH-120,140,160IRA/ERA-3			
		1/4	GSH-60IRA/ERA			
	Gas-side Service Valve	5 /9	GSH-80,100,120,140,160IRA/ERA			
2		5/8	GSH-120,140,160IRA/ERA-3			
		1/2	GSH-60IRA/ERA			
3	Handle	Used to cover or uncover the front case				
4	Air discharge Grill	/				

8.2.2 Space requirements for installation





8.2.3 Precautions on Installation of Outdoor Unit

- When moving outdoor unit, it is necessary to adopt 2 pieces of long enough rope to hand the unit from 4 directions. Included angle between the rope when hanging and moving must be 40° below to prevent center of the unit from moving.
- 4 Adopt M12 bolts components to tighten feet and under frame when installing.
- 4 Outdoor unit should be installed on concrete base that is 10cm height.
- Requirements on installation space dimension of unit's bodies are shown in following drawing.
- Outdoor unit must be lifted by using designated lifting hole. Take care to protect the unit during lift. To avoid rusting, do not knock the metal parts.

9. Installation of Indoor Unit

9.1 Select Installation Location of Indoor Unit

- Avoid direct sunshine.
- Ensure the hanger rod, ceiling and building structure have sufficient strength to support the weight of air conditioner unit.
- Drainage pipe is easy to connect out.
- ✤ Indoor and outdoor connection pipes are easy to go outdoors
- Do not install at a place where flammable or explosive goods exist or flammable or explosive gas might leak.
- Do not install at a place subject to corrosive gas, severe dust, salty fog, smoke or heavy moisture.
- ♣ Air flow at inlet and outlet air is not blocked.

9.2 Install process of indoor unit

Step1: Drilling hole on the wall in the following draw



Step2: Releasing screws, detach front cover from the indoor unit.



Step3: Attaching indoor unit to the wall make use of accessory expansion bolt.



! CAUTION!

While lifting the indoor unit, at least two persons should be joined. Weight of the indoor unit is almost 52kg.

9.3 Outline dimension of Indoor unit

GSH-60IRA, GSH-80IRA, GSH-100IRA, GSH-120IRA, GSH-140IRA, GSH-160IRA, GSH-120IRA-3, GSH-140IRA-3, GSH-160IRA-3 500 324 906 ٣ ۵



Decorintion

Description			Uint: inch	
No	Name		Remarks	
1	Leaving Water Pipe		1"Male BSP	
2	Returning Water Pipe	1"Male BSP		
		5/8	GSH-80,100,120,140,160IRA/ERA	
3	Gas-side Pipe	3/0	GSH-120,140,160IRA/ERA-3	
		1/2(GSH-60IRA/ERA)		
		2/8	GSH-80,100,120,140,160IRA/ERA	
4	Liquid-side Pipe	3/8	GSH-120,140,160IRA/ERA-3	
		1/4(GSH-60IRA/ERA)		

9.4 Space requirements for installation

GSH-60IRA, GSH-80IRA, GSH-100IRA, GSH-120IRA, GSH-140IRA, GSH-160IRA, GSH-120IRA-3, GSH-140IRA-3, GSH-160IRA-3



Service Space

9.5 Precautions on Installation of indoor Unit

- 9.5.1 Indoor unit shall be vertically mounted on the wall of the room with expansion bolt.
- 9.5.2 Keep the indoor unit away from heat sources like heat sink and so on in the room as much as possible.
- 9.5.3 Keep the indoor unit as close as possible to outdoor unit. Level distance between connection pipes can not exceed 30m(8.0~16KW) or 20m(6.0kw) and vertical distance can not exceed 15m(8.0~16KW) or 10m(6.0kw).

9.6 Water Volume and Pump capacity





Note:

- 1. The water pump is three speed-adjustable(maximum/medium/minimum), In most case, we strongly recommended to set speed as maximum;
- If the noise of the pump is not acceptable, we recommended change the default speed to medium speed, but to secure enough flow rate, do not set water speed as "Min", it can lead unexpected flow rate error "EC";

9.6 Water Volume and Expansion Vessel Pressure



Note:

- Expansion vessel is included which 10 liter and 1bar pre-pressure.
- Total water volume of 280 liter is default; If total water is changed because of installation condition, the pre-pressure should be adjusted to secure proper operation. If the indoor unit is located at the highest position, adjustment is not required;
- Minimum total water volume is 20 liter;

4 To adjust pre-pressure, use nitrogen gas by certificated installer.

9.7 The method of calculating the charging pressure of expansion vessel needed to be adjusted is as follows.

During installation, if the volume of water system has changed, please check if the pre-set pressure of the expansion vessel needs to be adjusted according to the following formula:

$$P_g = (H/10 + 0.3)$$
 Bar

(H ---the difference between installing location of indoor unit and the highest spot of water system.)

Ensure that the volume of water system is lower than the maximum volume required in the above figure. If it exceeds the range, the expansion vessel does not meet the installing requirement.

Installation height ¹	Water volume			
difference	<280L	>280L		
<7 m	Adjustment is not necessary	 Pre-set pressure needs to be adjusted according to the above formula. Check if the water volume is lower than the maximum water volume. (with help of the above figure) 		
>7 m	 Pre-set pressure needs to be adjusted according to the above formula. Check if the water volume is lower than the maximum water volume. (with help of the above figure) 	The expansion vessel is too small and adjustment is not available.		

¹Note: Installation height difference : -the difference between installing location of indoor unit and the highest spot of water system; if the indoor unit is located at the highest point of the installation, the installation height difference is considered 0m;

Example 1: The indoor unit is installed 5m below the outdoor unit and the total volume of the water system is 100L.

Referring to the above figure, it is not necessary to adjust the pressure of the expansion vessel.

Example 2: The indoor unit is installed on the highest spot of the water system and the total water volume is 350L.

- 1. As the volume of water system is higher than 280L, it is necessary to adjust the pressure of the expansion vessel be lower.
- 2. The formula of calculating pressure

$$P_g = (H/10 + 0.3) = (0/10 + 0.3) = 0.3$$
 Bar

- 3. The maximum volume of the water system is about 410L. As the actual volume of the water system is 350L, the expansion vessel meets the installing requirement.
- 4. Adjust the pre-set pressure of the expansion vessel from 1.0Bar to 0.3Bar.

9.8 Selection of expansion vessel

Formula:

$$\mathbf{v} = \frac{c \cdot e}{1 - \frac{1 + p_1}{1 + p_2}}$$

v --- Volume of expansion vessel

c--- Total water volume

 p_1 --- Pre-set pressure of expansion vessel

- p_2 -- The highest pressure during running of the system (that is the action pressure of safety valve.)
- *e*--- The expansion factor of water (the difference between the expansion factor of the original water temperature and that of highest water temperature.)

Water expansion factor in different temperature				
Temperature (°C)	Expansion factor e			
0	0.00013			
4	0			
10	0.00027			
20	0.00177			
30	0.00435			
40	0.00782			
45	0.0099			
50	0.0121			
55	0.0145			
60	0.0171			
65	0.0198			
70	0.0227			
75	0.0258			
80	0.029			
85	0.0324			
90	0.0359			
95	0.0396			
100	0.0434			

10. Connection of pipeline

10.1 Connection of Outlet Pipe for Indoor & Outdoor Unit

- Align the expansion end of copper pipe with the center of threaded joint. Tighten the flaring nuts with your hands.
- Tighten the flaring nuts with torque wrench until you hear a "click".
- Bend of fitting pipe shall not be too low; otherwise the fitting pipe might crack. Please use pipe bender when bending the fitting pipe.
- When connecting outdoor and indoor unit, never pull the big and small joint of indoor unit with force, so as to prevent the tubes of indoor unit from cracking and causing leakage.
- Connecting pipe shall be supported by a rack without transmitting its weight to other units.

Pipe of indoor unit Flaring nut Pipe Moment spanner

10.2 Installation of Protective Layer on Connection Pipe

- To avoid condensate dew or water leakage on connecting pipe, the air pipe and liquid pipe must be wrapped with heat preservation material and adhesive pipe for insulation from the air.
- The joints on indoor unit and outdoor unit must be wrapped with heat preservation materials and have no clearance against the wall surface of indoor unit and outdoor unit.
- > Wrap the pipe with tapes.
 - 1. Use the adhesive tape to wrap the connecting pipe and cable into one bundle. To prevent condensate water from overflowing out of the drainpipe, the drainpipe shall be separated from connecting pipe and cable.
 - 2. Wrap the heat preservation tape so that each ring of tape shall press half of the previous ring.
 - 3. Fix the wrapped pipe onto the wall with pipe clamp.
 - 4. Do not wrap the protective tape too tightly, as this will decrease the heat insulation performance.
 - 5. After completing the protection work and wrapping the pipe properly, close the wall holes with sealing materials.





Outdoor unit



model	Pipe size (Diameter: Φ)		Length B		Elevation A		Additional
	gas	Liquid	Standard	Max.	Standard	Max.	Temgerani
GSH-60IRA GSH-60ERA	1/2″	1/4″	5.0m	20m	0m	10m	20g/m
GSH-80IRA GSH-80ERA	5/8″	3/8″	7.5m	30m	0m	15m	50g/m
GSH-100IRA GSH-100ERA	5/8″	3/8″	7.5m	30m	0m	15m	50g/m
GSH-120IRA GSH-120ERA	5/8″	3/8″	7.5m	30m	0m	15m	50g/m
GSH-140IRA GSH-140ERA	5/8″	3/8″	7.5m	30m	0m	15m	50g/m
GSH-160IRA GSH-160ERA	5/8″	3/8″	7.5m	30m	0m	15m	50g/m
GSH-120IRA-3 GSH-120ERA-3	5/8″	3/8″	7.5m	30m	0m	15m	50g/m
GSH-140IRA-3 GSH-140ERA-3	5/8″	3/8″	7.5m	30m	0m	15m	50g/m
GSH-160IRA-3 GSH-160ERA-3	5/8″	3/8″	7.5m	30m	0m	15m	50g/m

Note:

1. No additional charge of the refrigerant is need when the pipe length is less than 10 m, if the pipe length is longer than 10m,additional charge of the refrigerant is needed according to the table.

Example:

If 16kw model is installed at a distance of 25m, (25-10)*50=750g refrigerant should be added;

- 2. Rated capacity is based on standard pipe length and maximum allowable length is base on the product reliability in the operation;
- 3. Oil trap should be installed every 5-7 meters when the location of outdoor unit is higher than indoor unit.

11. Remote Air Temperature Sensor



Installation Guide follow as:



Note:

1. Distance between the indoor unit and the remote air temperature senor should be less

than 15 meter due to length of the connection cable of remote air temperature sensor.

- 2. Height from floor is approximately 1.5 meter;
- 3. Remote air temperature sensor can not be located where the area may be hidden When door is open;
- 4. Remote air temperature sensor can not be located where external thermal influence may be applied;
- 5. Remote air temperature sensor should be installed where space heating is mainly applied;
- 6. After the Remote air temperature sensor is installed, should be set the value form "0" to "1" at the function code 1 in the control panel, so as to select remote air temperature to the control point;

12. Thermostat

Installation of Thermostat is very similar to that of Remote air temperature sensor,





How to Wire Thermostat

- i. Uncover the front cover of the indoor unit and open the control box.
- ii. Identify the power specification of the thermostat, if it is 230V, find terminal block
- iii. XT3 as NO.21 \sim 24; Otherwise, if it is 24V, find terminal blockXT3 as NO.25 \sim 28;
- iv. If it is Heating/Cooling thermostat, please connect wire as Fig 1;
- v. If it is Heating only thermostat, please connect wire as Fig 2;

- 1. NEVER USE 230V AC and 24V AC Thermostat at the same time, otherwise, it will cause short-circuit and power cut-off by circuit breaker;
- 2. Setting temperature by Thermostat(heating or cooling) should be chosen within the setting temperature range of the product ;
- 3. For other constrains, please refer to previous page where constrains about
- 4. Remote air temperature sensor;
- 5. Do not connect external electric loads, Wire (L) and (N) should be used only for operation Electric type thermostat;
- 6. Never connect external electric loads such as valves, fan coil units, etc. If connected, PCB of the indoor unit can be seriously damaged;
- 7. Installation of Thermostat is very similar to that of Remote air temperature sensor.

13. 2-Way Valve

2-way valve is required to control water flow while cooling operation. Role of 2-way valve is to cut off water flow into under floor loop in cooling mode when fan coil unit is equipped for cooling operation.

General Information

Туре	Power	Operating Mode	Supported
NO 2 min	2201/ 501/	Closing water flow	Yes
NO 2-wire	230V SUHZ \sim AC	Opening water flow	Yes
NG 2 min	22014 5014	Closing water flow	Yes
INC 2-WIFE	230V SUHZ \sim AC	Opening water flow	Yes

(1) : Normal Open type. When electric power is NOT supplied, the valve is open. (When electric power is supplied, the valve is closed.)

(2) : Normal Closed type. When electric power is NOT supplied, the valve is closed. (When electric power is supplied, the valve is open.)

How to Wire 2-Way Valve

Follow below procedures Step 1 ~ Step 2.

Step 1. Uncover front cover of the indoor unit and open the control box.

Step 2. Find terminal block and connect wire as below.

1		2		3	2	1	5	,	6	6
OFF	ON	I	N		OFF		ON	·	Ν	
NC	NC) 	N	I	NC	I	NO		N	1
2	2 way	valu	ue 1		2	wa	y va	alue	2	

WARNING

- Normal Open type should be connected to wire (NO) and wire (N)for valve closing in cooling mode.
- Normal Closed type should be connected to wire (NC) and wire (N)for valve closing in cooling mode.
- (NO) : Line signal (for Normal Open type) from PCB to 2-way valve
- (NC) : Line signal (for Normal Closed type) from PCB to 2-way valve
- (N) : Neutral signal from PCB to 2-way valve

14. 3-Way Valve

3-way valve is required to operate sanitary water tank. Role of 3-way valve is flow switching between under floor heating loop and water tank heating loop.

General Information

Туре	Power	Operating Mode	Supported
SPDT	2201/ 5011	Selecting "Flow A" between "Flow A" and "Flow B"	Yes
3-wire	$230V 50Hz \sim AC$	Selecting "Flow B" between "Flow B" and "Flow A"	Yes

(1) : SPDT = Single Pole Double Throw. Three wires consist of Live1 (for selecting (for selecting Flow B), and Neutral (for common).

(2) : Flow A means 'water flow from the indoor unit to under floor water circuit.'

(3): Flow B means 'water flow from the indoor unit to sanitary water tank.'

How to Wire 3-Way Valve

Follow below procedures Step 1 ~ Step 2.

Step 1. Uncover front cover of the indoor unit and open the control box.

Step 2. Find terminal block and connect wire as below.



WARNING

- 3-way valve should select water tank loop when electric power is supplied to wire (OFF) and wire (N).
- 3-way valve should select under floor loop when electric power is supplied to wire (ON) and wire (N).
- (OFF) : Line signal (Water tank heating) from PCB to 3-way valve
- (ON): Line signal (Under floor heating) from PCB to 3-way valve
- (N): Neutral signal from PCB to 3-way valve

15. Gate-controller

If there is gate control function, pull out the leading wire 50 on terminal board (XT2) between 19 and 20 and then connect the Gate-controller

Installation Guide follow as:



16. Filling of Refrigerant

- Before shipped out from manufacturer, the outdoor unit has been filled with refrigerant. Additional refrigerant may be filled when carrying out site connection of pipelines.
- Check the liquid valve and the gas valve of the outdoor unit. The valves shall be completely shut off.
- Connect a vacuum pump to the liquid valve and the gas valve of the outdoor unit to remove air from the inside of the indoor unit and the connecting pipe. Refer to the following figure:



Fig.22

- After confirming that there is no leakage from the system, when the compressor is not in operation ,charge additional R410A working fluid with specified amount to the unit through the filling opening of the liquid pipe valve of the outdoor unit.
 - Be sure to charge the specified amount of refrigerant in liquid state to the liquid pipe: Since this refrigerant is a mixed refrigerant , adding it in gas form may cause the refrigerant composition to change, preventing normal operation
 - Before charging, check whether the refrigerant cylinder is equipped with a siphon tube or not;



17. Installation of Insulated Water Tank

17.1 Installation measure

- The insulated water tank should be installed and keep levelly within 5m and vertically within 3m from the Indoor unit. It can be installed in the room.
- Standing water tank must be installed vertically with the bottom on the ground, never suspended. Installation place must be firm enough and the water tank should be fixed on the wall with bolts to avoid vibration, as shown in the following figure. Weight capacity of water tank during installation should also be considered.



- The minimum clearance from the water tank to combustible surface must be 500mm.
- There should be water pipe, hot water joint and floor drain near the water tank in favor of water replenishment, hot water supply and drainage of water tank.
- Connection of inlet/outlet waterway: Connect the safety check valve attached with the unit (→ points at insulated water tank) with the water inlet of water tank with PPR pipe according to the following figure, sealing with unsintered tape. The other end of the safety check valve should connect with tap water joint. Connect the hot water pipe and water outlet of water tank with PPR pipe.



Note: For safe use of water, water outlet/inlet of water tank must connect with a certain length of PPR pipe $L \ge 70 \times R^2(cm, R \text{ is inside radius of the pipe})$. Moreover, heat preservation should

be conducted and metal pipe can not be used. For the first use, water tank must be full of water before the power is on.



17.2 Outline dimension and parameter of water tank

		SXVD200LCJ/A-K	SXVD200LCJ2/A-K	SXVD300LCJ/A-K	SXVD300LCJ2/A-K	
		SXVD200LCJ/A-M	SXVD200LCJ2/A-M	SXVD300LCJ/A-M	SXVD300LCJ2/A-M	
Lit	re	200L	200L	300L	300L	
co	il		CLIC204	A 22 Y 0 0		
specifi	cation		SUS304 Φ 22X0.8			
coil	М	/	10m	/	10m	
length	Ν	13m	13m	18.5m	18.5m	
D(m	m)	5	40	6	20	
D1(n	nm)	4	38	52	28	
H(m	m)	15	595	16	520	
A(m	m)	2	72	2	80	
B(m	m)	105				
C(m	m)	112				
E(m	m)	4	32	464		
F(m	m)	4	31	399		
I(m	m)	/	80	/	95	
J(m	m)	/	247.5	/	202.5	
K(m	m)	7	39	7	18	
Outl	ine					
(Diame	ter×H)	Ф540	0Х1595 Ф620Х1620		X1620	
(mr	n)					
Pack (W*D*H	age) (mm)	1620X625X630		1645X7	05X710	
Net weight	kg	68	71	82	87	
Gross weight	kg	77	80	92	97	

Joints Dimension		
Description	Joint pipe thread	
Hot water outlet of water tank	1/2" Female BSP	
Circulating water inlet/outlet of water tank	3/4 " Female BSP	
Cooling water inlet of water tank	1/2" Female BSP	
Pipe joint	3/4 " Female BSP	

17.3 Connection of Waterway System

- If connection between water tank and indoor unit should be through the wall, drill a holeφ70 for pass of circulating water pipe. It is unnecessary if the hole is not needed.
- Preparation of pipelines: Circulating water outlet/inlet pipe must be hot water pipe, PPR pipe with nominal out diameter of dn25 and S2.5 series (wall thickness of 4.2mm) being recommended. Cooling water inlet pipe and hot water outlet pipe of water tank should also be hot water pipe, PPR pipe with nominal out diameter of dn20 and S2.5 series (wall thickness of 3.4mm) being recommended. If other insulated pipes are adopted, refer to the above dimensions for out diameter and wall thickness.
- Installation of circulating water inlet/outlet pipes: Connect the water inlet of unit with circulating outlet of water tank and water outlet of unit with circulating inlet of water tank.
- Installation of water inlet/outlet pipes of water tank: Safety check valve (→ on the valve body points at water tank), filter and cut-off valve must be installed for water inlet pipe according to the installation sketch of unit. At least a cut-off valve is needed for the water outlet pipe.
- Installation of blow-off pipe at the bottom of water tank: Connect a piece of PPR pipe with drainage outlet to floor drain. A cut-off valve must be installed in the middle of the drainage pipe and at the place where it is easy to be operated by the users.
- After connection of all waterway pipelines, perform leakage test firstly (refer to debugging of the unit). After that, bind up the water pipes, water temp sensor and wires with wrapping tapes attached with the unit.
- Refer to Installation Sketch of Unit for details.



Joints Dimension		
Description	Joint pipe thread	
Circulating water inlet/outlet of main unit	1 "Male BSP	
Cooling water inlet of water tank	1/2" Female BSP	
Circulating water inlet/outlet of water tank	3/4 " Female BSP	
Hot water outlet of water tank	1/2" Female BSP	

▲ Note:

- Distance between indoor unit and water tank should not exceed 5m levelly and 3m vertically. If higher, please contact with us. Water tank on lower and main unit on higher side is recommended.
- Prepare the materials according to the above joints dimension. If cut-off valve is installed outside the room, PPR pipe is recommended to avoid freeze damage.
- Waterway pipelines can't be installed until water heater unit is fixed. Do not let dust and other sundries enter into pipeline system during installation of connection pipes.
- After connection of all waterway pipelines, perform leakage test firstly. After that, perform heat preservation of waterway system; meanwhile, pay more attention to valves and pipe joints. Ensure enough thickness of insulated cotton. If necessary, install heating device for pipeline to prevent the pipeline from freezing.
- Hot water supplied from insulated water tank depends on pressure of water tap, so there must be supply of tap water.
- During using, the cut-off valve of cooling water inlet of water tank should be kept normally on.

17.4 ELECTRIC WIRING WORK

17.4.1 Wiring Principle

General principles

- Wires, equipment and connectors supplied for use on the site must be in compliance with provisions of regulations and engineering requirements.
- Only electricians holding qualification are allowed to perform wire connection on the site.
- Before connection work is started, the power supply must be shut off.
- Installer shall be responsible for any damage due to incorrect connection of the external circuit of the unit.

Connection of power cable to the electric cabinet of the unit

- Power cables should be laid out through cabling trough, conduit tube or cable channel.
- Power cables to be connected into the electric cabinet must be protected with rubber or plastic to prevent scratch by edge of metal plate.
- Power cables close to the electric cabinet of the unit must be fixed reliably to make the power terminal in the cabinet free from an external force.

Power cable must be grounded reliably.

17.4.2 Specification of Power Supply Wire and Leakage Switch

Power cable specifications and Leakage switch types in the following list are recommended for selection.

Model	Power Supply	Leakage Switch	Minimum Sectional Area of Earth Wire	Minimum Sectional Area of Power Supply Wire
	V Ph Hz	(A)	(mm ²)	(mm ²)
GSH-60IRA		32	6	3×6
GSH-80IRA		50	10	3×10
GSH-100IRA		50	10	3×10
GSH-120IRA		50	10	3×10
GSH-140IRA	-	50	10	3×10
GSH-160IRA	$220\sim$	50	10	3×10
GSH-60ERA	240V-Ph-50Hz	32	6	3×6
GSH-80ERA		32	6	3×6
GSH-100ERA		32	6	3×6
GSH-120ERA		40	10	3×10
GSH-140ERA		40	10	3×10
GSH-160ERA	-	40	10	3×10
GSH-120IRA-3		16	2.5	5×2.5
GSH-140IRA-3		16	2.5	5×2.5
GSH-160IRA-3	380~	16	2.5	5×2.5
GSH-120ERA-3	415V-3Ph-50Hz	25	4.0	5×4.0
GSH-140ERA-3		25	4.0	5×4.0
GSH-160ERA-3		25	4.0	5×4.0

Note:

- I 、 Power cables are copper core cable and copper connectors must be used for power cable connection.
- II 、 Leakage Switch is necessary for additional installation. If circuit breakers with leakage protection are in use, action response time must be less than 0.1 second, leakage circuit must be 30mA.
- III、 The above selected power cable diameters are determined based on assumption of distance from the distribution cabinet to the unit less than 75m. If cables are laid out in a distance of 75m to 150m, diameter of power cable must be increased to a further grade.
- $\rm IV_{\sim}$ Indoor/outdoor supply cable should be H05RN-F or above.
- $\rm V$. The power supply must be of rated voltage of the unit and special electrical line for air-conditioning.
- $\rm VI$ \sim All electrical installation shall be carried out by professional technicians in accordance with the local laws and regulations.
- VII. Ensure safe grounding and the grounding wire shall be connected with the special grounding equipment of the building and must be installed by professional technicians.

18. Wring Diagram

18.1 PCB OUTLINE

18.1.1 GSH-60ERA, GSH-80ERA, GSH-100ERA



silk screen	Specification
AC-L	live wire input of power supply, red
Ν	zero wire input of power supply, white
E1	ground wire, yellow green
L2-2	PFC blue inductive wire
L1-1	PFC brown inductive wire
L2-1	PFC yellow inductive wire
L1-2	PFC white inductive wire
U	U-phase of compressor
V	V-phase of compressor
W	W-phase of compressor
DC_MOTOR1	DC fan 1 pin: strong power supply; 3 pin: fan GND; 4 pin: +15V; 5 pin: control signal; 6 pin: feedback signal;
4V 4V1	4-way valve
HEAT	electric heating tape
VA-1	e-heater of chassis
HPP	high pressure switch
LPP	low pressure switch
OVC-COMP	overload protection of compressor
T-SENSOR2	1, 2 hole: pipe temperature; 3, 4 hole: environment; 5, 6 hole: exhaust
T-SENSOR3	1 hole: +3.3V 2 hole: detection ; suction temperature sensor

CN66、CN67	communication cable 2 pin B, 3pinA
CN65	communication cable: 1 pin earthed, 2 pin B, 3 pin A, 4 pin+12power supply; It can not be used for communication between outdoor unit and indoor unit;
FA	pipe electric expansion valve 1-4 pin: driving impulse output; 5 pin: +12V;
H-PRESS	signal input of pressure sensor 1 pin: GND; 2 pin: signal input; 3 pin: +5V

18.1.2 GSH-120ERA, GSH-140ERA, GSH-160ERA



silk screen	specification
AC-L	live wire input of power supply, red
Ν	Neutral line input of power supply(PFC blue inductive wire) blue
L1-1	PFC brown inductive wire
L2-1	PFC yellow inductive wire
L1-2	PFC white inductive wire
U	U-phase of compressor
V	V-phase of compressor
W	W-phase of compressor
DC_MOTOR1	DC fan 1 pin: strong power supply; 3 pin: fan GND; 4 pin: +15V; 5 pin: control signal; 6 pin: feedback signal;
DC_MOTOR2	DC fan 1 pin: strong power supply; 3 pin: fan GND; 4 pin: +15V; 5 pin: control signal; 6 pin: feedback signal;
4V1	4-way valve

HEAT	electric heating tape
VA-1	e-heater of chassis
HPP	high pressure switch
LPP	low pressure switch
T-SENSOR2	1, 2hole: pipe temperature; 3, 4hole: environment; 5, 6hole: exhaust
T-SENSOR3	1 hole:+3.3V 2 hole: detection: suction temperature sensor
CN66、CN67	communication cable 2 pin B, 3 pin A
CN65	communication cable 1 pin earthed, 2 pin B, 3 pin A, 4 pin+12 power supply It can not be used for communication between outdoor unit and indoor unit.
FA	pipe electric expansion valve 1-4 pin: driving impulse output; 5 pin: +12V;
H-PRESS	signal input of pressure sensor 1 pin: GND; 2 pin: signal input; 3 pin: +5V

18.1.3 GSH-120ERA-3, GSH-140ERA-3, GSH-160ERA-3



silk screen	specification
L1	
L2	live wire input of power supply
L3	
Ν	Neutral line input of power supply
L	Reactor red inductive wire
U	U-phase of compressor
V	V-phase of compressor
W	W-phase of compressor

DC_MOTOR1	DC fan 1 pin: strong power supply; 3 pin: fan GND; 4 pin: +15V; 5 pin: control signal: 6 pin: feedback signal:
DC_MOTOR2	DC fan 1 pin: strong power supply; 3 pin: fan GND; 4 pin: +15V; 5 pin: control signal; 6 pin: feedback signal;
4V1	4-way valve
HEAT	electric heating tape
VA-1	e-heater of chassis
HPP	high pressure switch
LPP	low pressure switch
T-SENSOR2	1, 2hole: pipe temperature: 3, 4hole: environment: 5, 6hole: exhaust
T-SENSOR3	1 hole:+3.3V 2 hole: detection: suction temperature sensor
CN66、CN67	communication cable 2 pin B, 3 pin A
CN65	communication cable 1 pin earthed, 2 pin B, 3 pin A, 4 pin+12 power supply It can not be used for communication between outdoor unit and indoor unit.
FA	pipe electric expansion valve 1-4 pin: driving impulse output; 5 pin: +12V;
H-PRESS	signal input of pressure sensor 1 pin: GND; 2 pin: signal input; 3 pin: +5V

18.1.4 GSH-60IRA, GSH-80IRA, GSH-100IRA, GSH-120IRA, GSH-140IRA, GSH-160IRA, GSH-120IRA-3, GSH-140IRA-3, GSH-160IRA-3



silk screen	location	specification
AC-L	-	live wire of power supply
N	-	Neutral wire of power supply
PUMP1	X13	live wire of indoor water pump
PUMP2	X14	live wire of solar water pump
RUN	X15	running indicator
HEAT3-L	X16	e-heater of water tank
HEAT1-L	X17	e-heater of indoor unit 1
HEAT2-L	X18	e-heater of indoor unit 2
ERR	X19	error indicator
2V1_OFF	X5	Electric magnetic 2-way valve1 is normally closed.
2V1_ON	X6	Electric magnetic 2-way valve1 is normally open.
2V2_OFF	X7	Electric magnetic 2-way valve2 is normally closed.
2V2_ON	X8	Electric magnetic 2-way valve2 is normally open.
3V1_OFF	X9	Electric magnetic 3-way valve1 is normally closed.
3V1_ON	X10	Electric magnetic 3-way valve1 is normally open.
3V2_OFF	X11	Electric magnetic 3-way valve2 is normally closed.
3V2_ON	X12	Electric magnetic 3-way valve2 is normally open.
T-SENSOR1	CN10	terminal of temperature sensor1
T-SENSOR2	CN11	terminal of temperature sensor2
T-SENSOR3	CN12	terminal of temperature sensor3
T-SENSOR4	CN13	terminal of temperature sensor4
T-SENSOR5	CN14	terminal of temperature sensor5
T-SENSOR6	CN15	terminal of temperature sensor6
DOOR-C	CN23	Door detection input
OVC-HEAT3	CN28	e-heater of water tank adhesion-proof protection detector
OVC-HEAT1	CN26	e-heater of indoor unit1 adhesion-proof protection detector
OVC-HEAT2	CN27	e-heater of indoor unit2 adhesion-proof protection detector
IN-SW	CN25	detection input of water flow switch
COM-MANUAL	CN6	connect the wired controller
COM-OUT	CN5	connect to outdoor unit
COM-BMS	CN7	connect to remote controller
TR-OUT1	CN2	transformer output 1
TR-OUT2	CN3	transformer output 2
TR-IN	CN1	220V in put of transformer
CN30	CN30	heavy-current interface of end controller
CN31	CN31	heavy-current interface of end controller

18.2 ELECTRIC WIRING WORK

18.2.1 Wiring Principle

① General principles

- Wires, equipment and connectors supplied for use on the site must be in compliance with provisions of regulations and engineering requirements.
- Only electricians holding qualification are allowed to perform wire connection on the site.
- Before connection work is started, the power supply must be shut off.
- Installer shall be responsible for any damage due to incorrect connection of the external circuit of the unit.
- Caution --- MUST use copper wires.

2 Connection of power cable to the electric cabinet of the unit

- Power cables should be laid out through cabling trough, conduit tube or cable channel.
- Power cables to be connected into the electric cabinet must be protected with rubber or plastic to prevent scratch by edge of metal plate.
- Power cables close to the electric cabinet of the unit must be fixed reliably to make the power terminal in the cabinet free from an external force.
- Power cable must be grounded reliably.

18.2.2 Electric Wiring Design

18.2.2.1 Wiring Diagram: Indoor Unit GSH-60IRA, GSH-80IRA, GSH-100IRA, GSH-120IRA, GSH-140IRA, GSH-160IRA



GSH-120IRA-3, GSH-140IRA-3, GSH-160IRA-3



18.2.2.2 Wiring Diagram: Outdoor Unit



GSH-60ERA GSH-80ERA, GSH-100ERA

GSH-120ERA, GSH-140ERA, GSH-160ERA





GSH-120ERA-3, GSH-140ERA-3, GSH-160ERA-3,



- Specification:
- 1. Running indicating lamp(HL1) and Error indicating lamp (HL2) are connected or not on the basis of the clients'demand.
 - Client water pump AC contactor(KM4) is back-up Pump for the future , so it is not be connect; Ń
 - is necessary for additional installation, Please reference to page 37 17.4.2 Specification of Power Supply Wire and Leakage Switch. Leakage Switch (LK) က်

18.2.2.3 Wiring Diagram: Indoor AND Outdoor Unit(Including Field Wiring) GSH-60IRA/ERA, GSH-80IRA/ERA,GSH-100IRA/ERA, GSH-12IRA/ERA,GSH-140IRA/ERA, GSH-160IRA/ERA



GSH-12IRA/ERA-3, GSH-140IRA/ERA-3, GSH-160IRA/ERA-3

Specification:

- 1, Running indicating lamp(HL1) and Error indicating lamp (HL2) are connected or not on the basis of the clients'demand.
 - Client water pump AC contactor(KM4) is back-up Pump for the future, so it is not be connect; Ń
- Leakage Switch (LK) is necessary for additional installation, Please reference to page 37 17.4.2 Specification of Power Supply Wire and Leakage Switch. က်

49

18.2.2.4 Terminal Board Information

GSH-60IRA/ERA, GSH-80IRA/ERA, GSH-100IRA/ERA, GSH-12IRA/ERA, GSH-140IRA/ERA, GSH-160IRA/ERA



GSH-12IRA/ERA-3, GSH-140IRA/ERA-3, GSH-160IRA/ERA-3



19. Debugging Operation of Unit

19.1 Check before Startup

For safety of users and unit, the unit must be started up for check before debugging. The procedures are as below:

	The following items shall be performed by qualified repair persons.							
Confirm followin	together with the sales engineer, dealer, installing contractor and customers t g items having been finished or to be finished.	forthe						
No.	Confirmation of Installation							
1	If the contents of Application for Installation of this Unit by Installer are real. If not, debugging will be refused.							
2	If there is written notice in which amend project is shown to the installer in respect of unqualified installation.							
3	If Application for Installation of unit by Installer and Debugging list are filed together.							
No.	Pre-check							
1	If appearance of the unit and internal pipeline system is ok during conveying, carrying or installation.							
2	Check the accessories attached with the unit for quantity, package and so on.							
3	Make sure there is drawings in terms of electricity, control, design of pipeline and so on.							
4	Check if installation of the unit is stale enough and there is enough space for operation and repair.							
5	Completely test refrigerant pressure of each unit and perform leakage detection of the unit.							
6	Check if water tank is installed stably and its bearing is safe upon it is full.							
7	Check if heat insulating measures for the water tank, outlet/inlet pipes and water replenishing pipe are proper.							
8	Check if nilometer of water tank, water temperature indicator, controller, manometer, pressure relief valve and automatic discharge valve etc. are installed and operate properly.							
9	Check if power supply accords with the nameplate and model of power cord conform to applicable requirements.							
10	Check if power supply and control wiring is connect properly according to wiring diagram, earthing is safe and each terminal is stable.							
11	Check if connection pipe, water pump, manometer, thermometer, valve etc. are installed properly.							
12	Check if each valve in the system is open or closed according to requirements.							
13	Confirm that the customers and inspection personnel of Part A are at site.							
14	Installation Check-up Table is completed and ask installing contractor's signature for consent.							
At	tention: If the items with ×, please notify the contractor .The above items are recommended.							
	General Evaluation: Debugging Amendment							
ç	Judge the following items (if there is not any filling, qualification will be regarded.)							
pnf	a: Power supply and electric control system b Loading calculation							
irm	c: Heating problems of Unit d: Noise problem							
-ch	e: Pipeline problem f: Others							
ltems a ecking	Normal debugging work can't be performed unless all installation items are qualified. If prob must be solved firstly. All costs will be installer's responsibility for delay of debugging re-debugging incurred by any problem which is not solved immediately.	lem, it g and						
fte	Submit schedule of amending reports to installer.							
r	If provide written amending report to installer which should be signed after communication. Yes () No ()							

19.2 Test run

Test run is testing whether the unit can run normally via preoperation. If the unit can not run normally, find and solve the engineering or unit problem until the test run is satisfactory. All

inspection must meet the requirements before performing the test run. Test run should follow the content and steps of the table below:

The follo	The following procedure should be executed by experience and qualified maintenance man.								
No.		start up the pretest procedure							
Notice: to cause case	before te sualty.	efore test, ensure that all power must be cut off including far- end power switch. Otherwise, it may sualty.							
1	-	Ensure that the compressor of the unit is preheated for 8h.							
Caution: to prever when sta	on: heat the lubricating oil at least 8h in advance, vent the refrigerant from mixing with the lubricating oil, which may cause damage to the compressor starting up the unit.								
2	Check whether the oil temperature of the compressor is obviously higher than the outdoor ambient temperature.								
temperate damaged	tion: if ure, it m l easily.	the oil temperature of the compressor is obviously higher than the outdoor ambient neans that the heating tape of compressor is damaged. In that case, the compressor will be Therefore, repair the heating tape Before using the unit.							
3	Check seque	whether the phase sequence of main power supply is correct. If not, correct the phase nce according to specification.							
the unit.	check th	e phase sequence before start-up to avoid inversion of the compressor which may damage							
4	outdoo	Apply universal electric meter to measure the insulation resistance between each or phase and earth as well as between phases.							
🛕 Caut	tion: de	fective earthing may cause electric shock.							
No.		Ready to start							
1	Cut off electric	f all of temporary power supply, resume all the insurance and check the city for the last time.							
	Check within	the power supply and voltage of the control circuit;V must be ±10% the range of rated operating power.							
No.		Start up the unit							
1	Check require	all the conditions needed to start up the unit: oil temperature, mode, ed load ect.							
2	Start u valve,	p the unit, and observe the operation of compressor, electric expanding fan motor and water pump ect.							
2	Note:	the unit will be damaged under abnormal running state.							
affixed in	nformat	ion:							
		Estimation or suggestion on the general running situation: good, modify							
		accordance with the requirements.)							
		a. problem of power supply and electric control system:							
		b. problem of load calculation:							
Items	for	d. noise problem:							
accept afte	ance er	e. problem of indoor and piping system: h. other problems							
debug	ging	During operation, it is needed to charge for the maintenance due to non-quality problems such as incorrect installation and maintenance.							
		Acceptance situation:							
		Is the user trained according to the specification? Please sign. Yes () No ()							

20. Daily Operation and Maintenance

- In order to avoid damage of unit, all protecting devices in the unit had been set before outgoing, so the user can never adjust or remove them.
- For the first startup of the unit or next startup of unit after long-period stop (above 1 day)by cutting off the power, please electrify the unit in advance to preheat the unit for more than 8hr
- Never put sundries on the unit and accessories. Keep dry, clean and ventilated around the unit. Remove the dust accumulated on the condenser fin timely to ensure performance of unit and to avoid stop of unit for protection.
- In order to avoid protection or damage of unit caused by blockage of water system, clean the filter in water system periodically and frequently check water replenishing device.
- In order to ensure anti-freezing protection, never cut off the power if ambient temp. is below zero in winter.
- In order to avoid frost crack of the unit, water in the unit and pipeline system not used for a long period should be drained. In addition, open the end cap of water tank for drainage.
- Never frequently make the unit on/off and close manual valve of water system during operation of unit by users.
- Ensure frequently check the working condition of each part to see if there is oil stain at pipeline joint and charge valve to avoid leakage of refrigerant.
- If malfunction of the unit is out of control of users, please timely contact with authorized service center of company.

NOTE:

The water pressure gage is installed in returning water line in the indoor unit, Please adjust the hydraulics system pressure according to next item:

- 1. If the pressure is less than 0.5 bar, please recharge the water immediately;
- 2. when recharging, the hydraulics system pressure should be not more than 2.5Bar.

Troub	lesho	oting
-------	-------	-------

Malfunctions	Reasons	Troubleshooting
Compressor does not start up	 A. Power supply has problem B. Connection wire is loose. C. Malfunction of mainboard D. Malfunction of compressor 	 Phase sequence is reverse Check out and re-fix Find out the reasons and repair. Replace compressor
High noise of fan	 A. Fixing bolt of fan is loose B. Fan blade touches shell or grill C. Operation of fan is unreliable 	 Re-fix fixing bolt of fan Find out the reasons and adjust Replace fan
High noise of compressor	 A. Liquid slugging happens when liquid refrigerant enters into compressor B. Internal parts in compressor are broken 	 Check if expansion valve is failure and temp. sensor is loose .If that, repair it. Replace compressor
Water pump does not run or runs abnormally	A. Malfunction of power supply or terminalB. Malfunction of relayC. There is air in water pipe	 Find out the reasons and repair Replace relay Evacuate
Compressor starts or stops frequently	 A. Poor or excess refrigerant B. Poor circulation of water system C. Low load 	 Discharge or add part of refrigerant Water system is blocked or there is air in it. Check water pump, valve and pipeline. Clean water filter or evacuate Adjust the load or add accumulating devices.
The unit does not heat although compressor is running	 A. Leakage of refrigerant B. Malfunction of compressor 	 Repair by leakage detection and add refrigerant Replace compressor
Poor efficiency of hot water heating	 A. Poor heat insulation of water system B. Poor heat exchange of evaporator C. Poor refrigerant of unit D. Blockage of heat exchanger at water side 	 Enhance heat insulation efficiency of the system Check if air in or out of unit is normal and clean evaporator of the unit Check if refrigerant of unit leaks Clean or replace heat exchanger.

The	table	of	error	code	
-----	-------	----	-------	------	--

Error code	Error description				
F4	Malfunction of outdoor environment temperature sensor				
F6	Malfunction of defrost temperature sensor				
F7	Malfunction of discharge temperature sensor				
F5	Malfunction of suction temperature sensor				
EF	Malfunction of outdoor fan				
E5	Overload proection of compressor or malfunction of driver				
E1	High pressure protection of compressor				
E3	Low pressure protection of compressor				
E4	high-temperature protection of discharge				
C5	Malfunction of indoor capacity switch				
E6	Communications failure between outdoor and indoor mainboard				
E6	Communications failure between outdoor mainboard and wired controller				
E3	Malfunction of refrigerant lack				
Fc	Malfunction of high pressure sensor				
F9	Malfunction of outlet temperature sensor				
dH	Malfunction of backup outlet temperature sensor				
F1	Malfunction of liquid pipe temperature sensor inside refrigerant				
F8	Malfunction of inlet temperature sensor				
FE	Malfunction of the second sanitary water tank temperature sensor				
FL	Malfunction of the first sanitary water tank temperature sensor				
F3	Malfunction of gas pipe temperature sensor inside refrigerant				
dF	Malfunction of solar outlet temperature sensor				
F0	Malfunction of remote room temperature sensor				
Ec	Malfunction of water switch				
E2	Indoor anti-frozen protetion				
No display	Over temperature of sanitary water tank temperature				
Ed	Over temperature of outlet temperature(No display on the screen)				
No display	Over temperature of solar outlet temperature				
EH	Malfunction of internal electric heater				
EH	Malfunction of the first internal electric heater connection				
EH	Malfunction of the second internal electric heater connection				
EH	Malfunction of sanitary water tank electric heater connection				
dU	Pull-out of the gate-controller				

21. Parameter Lists

	AIR TO WATER HEAT PUMPPERFORMANCE									
Model				GSH-60IRA/ERA	GSH-80IRA/ERA	GSH-100IRA/ERA	GSH-12IRA/ERA	GSH-140IRA/ERA	GSH-160IRA/ERA	
Capacity ¹	Heatir	ng (floor)	kW	6.2	8.5	10	12	14	16	
Capacity	Coolir	ng (floor)	kW	5.5	9.0	10.5	14	15	15.5	
Power	Heatir	ng (floor)	kW	1.5	2.1	2.50	2.67	3.33	3.9	
Input ¹	Coolin	ng (floor)	kW	1.6	2.5	3.14	3.68	4.28	4.62	
EER^1	Coolin	ng (floor)	-	3.4	3.6	3.35	3.8	3.5	3.35	
COP ¹	Heatir	ng (floor)	-	4.1	4.0	4.0	4.5	4.2	4.0	
$Capacity^2$	Heatin	ng (FCU)	kW	5.5	8.0	9.0	11.5	13	14	
Capacity	Cooling (FCU)		kW	4	6.5	8.0	10	11	11.5	
Power	Heatin	ng (FCU)	kW	1.8	2.65	2.9	3.35	3.88	4.59	
Input ²	Coolii	ng (FCU)	kW	1.53	2.5	3.08	3.45	3.93	4.2	
EER ²	Coolii	ng (FCU)	-	2.6	2.6	2.6	2.9	2.8	2.5	
COP ²	Heatin	ng (FCU)	-	3.0	3.0	3.1	3.4	3.35	3.05	
Pow	er Supp	ly	V/Ph/Hz	220~240/1/50						
Refrigerant		Туре	-	R410A	R410A	R410A	R410A	R410A	R410A	
Kenigerant	Charge		g	1700	2000	2000	3300	3300	3300	
Sanitary wa	ater Ten	nperature	°C	40-80	40-80	40-80	40-80	40-80	40-80	
Sound P	ressure	Level	dB(A)	59	59	59	59	59	62	
Gas Pipir	ng Conr	nection	mm	12.7	15.9	15.9	15.9	15.9	15.9	
Liquid Piping Connection		mm	6.35	9.52	9.52	9.52	9.52	9.52		
		Unit(W×	mm	921×427	921×427	921×427	950×412	950×412	950×412	
	Out	D× H)	mm	×791	×791	×791	×1253	×1253	×1253	
Dimensions	door unit	Packed unit(W×D × H)	mm	1065×485 ×840	1065×485 ×840	1065×485 ×840	1110×450 ×1385	1110×450 ×1385	1110×450 ×1385	

21.1 Product Data at Rated Condition

AIR TO WATER HEAT PUMPPERFORMANCE							
		Model		GSH-12IRA/ERA-3	GSH-140IRA/ERA-3	GSH-160IRA/ERA-3	
Consoitul]	Heating (floor)	kW	12	14	15	
Capacity	(Cooling (floor)	kW	14	15	15.5	
Power]	Heating (floor)	kW	2.8	3.33	3.9	
Input ¹	(Cooling (floor)	kW	3.8	4.28	4.4	
EER^1	(Cooling (floor)	-	3.8	3.5	3.5	
COP ¹	1	Heating (floor)	-	4.5	4.2	4.0	
$Capacity^2$		Heating (FCU)	kW	11	12	14	
Capacity		Cooling (FCU)		10	10.5	11	
Power		Heating (FCU)		3.35	3.8	4.2	
Input ²	Cooling (FCU)		kW	3.45	3.6	4	
EER ²		Cooling (FCU)	-	2.9	2.8	2.7	
COP ²		Heating (FCU)	-	3.4	3.35	3.2	
	Powe	r Supply	V/Ph/Hz	380~415/3/50			
Pefrigerant	Type		-	R410A	R410A	R410A	
Kenigerant		Charge	g	3500	3500	3500	
Sani	tary wat	ter Temperature	°C	40-80	40-80	40-80	
S	ound Pr	essure Level	dB(A)	59	59	62	
Ga	as Piping	g Connection	mm	15.9	15.9	15.9	
Liq	uid Pipi	ng Connection	mm	9.52	9.52	9.52	
Dimonsions	Out	Unit(W×D× H)	mm	950×412×1253	950×412×1253	950×412×1253	
Dimensions	unit	Packed unit(W×D× H)	mm	1110×450×1385	1110×450×1385	1110×450×1385	

Note:

- ¹Capacities and power inputs are based on the following conditions:
- ①.Cooling conditions -
 - Indoor Water Temperature 23°C/18°C;

Outdoor Air Temperature 35°CDB/24°CWB

2.Heating conditions

Indoor Water Temperature 30°C/35°C

Outdoor Air Temperature 7°CDB/6°CWB

- ③.Standard piping length 7.5m
- ² Capacities and power inputs are based on the following conditions:
- $\textcircled{1}. Cooling \ conditions$

Indoor Water Temperature 12°C/7°C;

Outdoor Air Temperature 35°CDB/24°CWB

- Heating conditions
 - Indoor Water Temperature 40°C/45°C;

Outdoor Air Temperature 7°CDB/6°CWB

3 Standard piping length 7.5m

	INDOOR UNIT								
	Model				GSH-80IRA	GSH-100IRA	GSH-12IRA	GSH-140IRA	GSH-160IRA
	Power St	upply	V/Ph/Hz			220~240/	1/50		
H	Rated input (ir	ndoor only)	W	3200		6200			
	Liquid s	ide diameter	mm (inch)	6.35(1/4)		9.52(3/8)		
	Gas s	ide diameter	mm (inch)	12.7(1/2)		15.9(5/	(8)		
Opera	tion Range	Cooling (FCU)	°C			7-25			
		Cooling (Floor)	°C			18-25	5		
(Outf	low water	Heating (FCU)	°C		25-55	(High Tempe	rature Cycle	e)	
te	emp.)	Heating (Floor)	°C		25-45	(Low Tempe	rature Cycle	e)	
		Туре	-	Water-cooled					
	pump	Nr. of speed	-	3					
		Power input	W	200					
		Water flow limit	LPM	7.5					
		Volume	Liter	10					
	Expansion Vessel	Water Pressure (Max)	Bar		3		3		
Main comp	vesser	Water Pressure (Pre)	Bar	1					
onents		Туре	-			Sheat	h		
		Material	-	Stainless Steel					
	Electric	Operation	-			Automa	tic		
	Heater	Steps	-			2	-		
		Capacity	KW	3	3 6				
		Combination Dower input	$\Phi/V/U_{\pi}$	1.5+1.5		1/220/	5		
	Heat	Type	Ψ/ ν/ΠΖ			I/230/. Brazed Plat	A HEY		
	Exchanger	Ouantity	-			1	UTEA		
Dime	Unit	(W×D×H)	mm	900×500×324					
nsions	Packed	unit(W×D× H)	mm	1040×605×380					

	INDOOR UNIT							
		Model		GSH-12IRA-3 GSH-140IRA-3 GSH-160IRA-3				
	Power Su	pply	V/Ph/Hz	380~415/3/50				
Ra	ated input (inc	door only)	W	6200				
	Liquid sid	de diameter	mm (inch)	9.52(3/8)				
	Gas sic	le diameter	mm (inch)	15.9(5/8)				
		Cooling (FCU)	°C	7-25				
Opera	ation Range	Cooling (Floor)	°C	18-25				
(Out	flow water temp.)	Heating (FCU)	°C	25-55(High Temperature Cycle)				
		Heating (Floor)	°C	25-45(Low Temperature Cycle)				
		Туре	-	Water-cooled				
	numn	Nr. of speed	-	3				
	pump	Power input	W	200				
		Water flow limit	LPM	7.5				
	Expansio n Vessel ai m	Volume	Liter	10				
		Water Pressure (Max)	Bar	3				
Mai n com		Water Pressure (Pre)	Bar	1				
pon		Туре	-	Sheath				
ents		Material	-	Stainless Steel				
	Electric	Operation	-	Automatic				
	Heater	Steps	-	l l				
		Capacity	17 M	6				
		Combinatio n	ĸw	6				
		Power input	$\Phi/V/Hz$	3/400/50				
	Heat	Туре	-	Brazed Plate HEX				
	Exchange r	Quantity	-	1				
Dim	Unit(W	V×D× H)	mm	900×500×324				
ensi ons	Packed un	it(W×D× H)	mm	1040×605×380				

21.2 Operation Range

Mode	Range of Outdoor Temperature(°C)
Heating	-20~35
Cooling	10~48
Water heating	-20~45

Manufacturer:

Sinclair Corporation Ltd., 1-4 Argyll Street, London W1F 7LD, UK

Supplier and technical support: Nepa, spol.s.r.o. Purkyňova 45 612 00 Brno Czech Republic www.nepa.cz

Toll-free info line: +420 800 100 285

CE