USER'S MANUAL

EN

FOCUS SERIES outdoor unit

ASH-09BIF, ASH-13BIF, ASH-18BIF, ASH-24BIF



"Original instructions"

IMPORTANT NOTE:

Read this manual carefully before installing or operating your new air conditioning unit. Make sure to save this manual for future reference.

Content

Operation Notices

The Refrigerant	1
Precautions	
Parts Name	7

Installation Notice

Safety operation of flammable refrigerant	8
Installation dimension diagram	
Safety precautions for installing and relocating the unit	11
Tools for installation	12
Selection of installation location	12
Requirements for electric connection	13

Installation

Installation of outdoor unit	.14
Vacuum pumping	17
Leakage detection	.17
Check after installation	.18

Test and operation

Attachment

Configuration of connection pipe	19
Pipe expanding method	21

This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety. Children should be supervised to ensure that they do not play with the appliance.

If it needs to install, move or maintain the air conditioner, please contact dealer or local service center to conduct it at first. Air conditioner must be installed, moved or maintained by appointed unit. Otherwise, it may cause serious damage or personal injury or death.



This marking indicates that this product should not be disposed with other household wastes throughout the EU. To prevent possible harm to the environment or human health from uncontrolled waste disposal, recycle it responsibly to promote the sustainable reuse of material resources. To return your used device, please use the return and collection systems or contact the retailer where the product was purchased. They can take this product for environmental safe recycling.

R32: 675

Explanation of Symbols





Indicates a hazardous situation that, if not avoided, will result in death or serious injury.

Indicates a hazardous situation that, if not avoided, could result in death or serious injury.

Indicates a hazardous situation that, if not avoided, may result in minor or moderate injury.

Indicates important but not hazard-related information, used to indicate risk of property damage.



Indicates a hazard that would be assigned a signal word WARNING or CAUTION.

Please read this operating manual carefully before operating the unit.



Appliance filled with flammable gas R32.

Before use the appliance, read the owner's manual first.



Before install the appliance, read the installation manual first.

Before repair the appliance, read the service manual first.

The figures in this manual may be different with the material objects, please refer to the material objects for reference.

The Refrigerant

- To realize the function of the air conditioner unit, a special refrigerant circulates in the system. The used refrigerant is the fluoride R32, which is specially cleaned. The refrigerant is flammable and inodorous. Furthermore, it can leads to explosion under certain conditions. But the flammability of the refrigerant is very low. It can be ignited only by fire.
- Compared to common refrigerants, R32 is a nonpolluting refrigerant with no harm to the ozonosphere. The influence upon the greenhouse effect is also lower. R32 has got very good thermodynamic features which lead to a really high energy efficiency. The units therefore need a less filling.

WARNING:

Do not use means to accelerate the defrosting process or to clean, other than those recommended by the manufacture.Should repair be necessary, contact your nearest authorized Service Centre.

Any repairs carried out by unqualified personnel may be dangerous.

The appliance shall be stored in a room without continuously operating ignition sources. (for example: open flames , an operating gas appliance or an operating electric heater.)

Do not pierce or burn.

Appliance shall be installed, operated and stored in a room with a floor area larger than "X"m² (see table 1).(only applies to appliances that are not fixed appliances) Appliance filled with flammable gas R32. For repairs, strictly follow manufacturer's instructions only.

Be aware that refrigrants not contain odour.

Read specialist's manual.



Operation and Maintenance

- •This appliance can be used by children aged from 8 years and above and persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning use of the appliance in a safe way and understand the hazards involved.
- •Children shall not play with the appliance.
- •Cleaning and user maintenance shall not be made by children without supervision.
- •Do not connect air conditioner to multi-purpose socket. Otherwise, it may cause fire hazard.
- •Do disconnect power supply when cleaning air conditioner. Otherwise, it may cause electric shock.
- •If the supply cord is damaged, it must be replaced by the manufacturer, its service agent or similarly qualified persons in order to avoid a hazard.
- •Do not wash the air conditioner with water to avoid electric shock.
- •Do not spray water on indoor unit. It may cause electric shock or malfunction.
- •After removing the filter, do not touch fins to avoid injury.
- •Do not use fire or hair dryer to dry the filter to avoid deformation or fire hazard.

WARNING

- Maintenance must be performed by qualified professionals. Otherwise, it may cause personal injury or damage.
- Do not repair air conditioner by yourself. It may cause electric shock or damage. Please contact dealer when you need to repair air conditioner.
- Do not extend fingers or objects into air inlet or air outlet. It may cause personal injury or damage.
- Do not block air outlet or air inlet. It may cause malfunction.
- Do not spill water on the remote controller, otherwise the remote controller may be broken.
- When below phenomenon occurs, please turn off air conditioner and disconnect power immediately, and then contact the dealer or qualified professionals for service.
 - Power cord is overheating or damaged.
 - There's abnormal sound during operation.
 - Circuit break trips off frequently.
 - Air conditioner gives off burning smell.
 - Indoor unit is leaking.
- If the air conditioner operates under abnormal conditions, it may cause malfunction, electric shock or fire hazard.
- When turning on or turning off the unit by emergency operation switch, please press this switch with an insulating object other than metal.
- Do not step on top panel of outdoor unit, or put heavy objects. It may cause damage or personal injury.

Attachment

- Installation must be performed by qualified professionals. Otherwise, it may cause personal injury or damage.
- Must follow the electric safety regulations when installing the unit.
- According to the local safety regulations, use qualified power supply circuit and circuit break.
- Do install the circuit break. If not, it may cause malfunction.
- An all-pole disconnection switch having a contact separation of at least 3mm in all poles should be connected in fixed wiring.
- Including an circuit break with suitable capacity, please note the following table. Air switch should be included magnet buckle and heating buckle function, it can protect the circuit-short and overload.
- Air Conditioner should be properly grounded. Incorrect grounding may cause electric shock.
- Don't use unqualified power cord.
- Make sure the power supply matches with the requirement of air conditioner.Unstable power supply or incorrect wiring or malfunction. Please install proper power supply cables before using the air conditioner.
- Properly connect the live wire, neutral wire and grounding wire of power socket.
- Be sure to cut off the power supply before proceeding any work related to electricity and safety.

- Do not put through the power before finishing installation.
- If the supply cord is damaged, it must be replaced by the manufacturer, its service agent or similarly qualified persons in order to avoid a hazard.
- The temperature of refrigerant circuit will be high, please keep the interconnection cable away from the copper tube.
- The appliance shall be installed in accordance with national wiring regulations.
- Installation must be performed in accordance with the requirement of NEC and CEC by authorized personnel only.
- The air conditioner is the first class electric appliance. It must be properly grounding with specialized grounding device by a professional. Please make sure it is always grounded effectively, otherwise it may cause electric shock.
- The yellow-green wire in air conditioner is grounding wire, which can't be used for other purposes.
- The grounding resistance should comply with national electric safety regulations.
- The appliance must be positioned so that the plug is accessible.
- All wires of indoor unit and outdoor unit should be connected by a professional.
- If the length of power connection wire is insufficient, please contact the supplier for a new one. Avoid extending the wire by yourself.

- For the air conditioner with plug, the plug should be reachable after finishing installation.
- For the air conditioner without plug, an circuit break must be installed in the line.
- If you need to relocate the air conditioner to another place, only the qualified person can perform the work. Otherwise, it may cause personal injury or damage.
- Select a location which is out of reach for children and far away from animals or plants. If it is unavoidable, please add the fence for safety purpose.
- The indoor unit should be installed close to the wall.
- Instructions for installation and use of this product are provided by the manufacturer.

Working temperature range


For some models:

	Indoor side DB/WB(°C)	Outdoor side DB/WB(℃)
Maximum cooling	32/23	43/26
Maximum heating	27/-	24/18

NOTICE:

• The operating temperature range (outdoor temperature) for cooling only unit is -15° C ~ 43° C; for heat pump unit is -15° C ~ 43° C.

Parts Name



NOTICE:

Actual product may be different from above graphics, please refer to actual products.

Qualification requirement for installation and maintenance man

- All the work men who are engaging in the refrigeration system should bear the valid certification awarded by the authoritative organization and the qualification for dealing with the refrigeration system recognized by this industry. If it needs other technician to maintain and repair the appliance, they should be supervised by the person who bears the qualification for using the flammable refrigerant.
- It can only be repaired by the method suggested by the equipment's manufacturer.

Installation notes

- The air conditioner is not allowed to use in a room that has running fire (such as fire source, working coal gas ware, operating heater).
- It is not allowed to drill hole or burn the connection pipe.
- The air conditioner must be installed in a room that is larger than the minimum room area. The minimum room area is shown on the nameplate or following table a.
- Leak test is a must after installation.

	10.10							. (••••	/					
	Charge amount (kg)	≤1.2	1.3	1.4	1.5	1.6	1.7	1.8	1.9	2	2.1	2.2	2.3	2.4	2.5
Minimum	floor location	/	14.5	16.8	19.3	22	24.8	27.8	31	34.3	37.8	41.5	45.4	49.4	53.6
	window mounted	/	5.2	6.1	7	7.9	8.9	10	11.2	12.4	13.6	15	16.3	17.8	19.3
alea(III)	wall mounted	/	1.6	1.9	2.1	2.4	2.8	3.1	3.4	3.8	4.2	4.6	5	5.5	6
	ceiling mounted	/	1.1	1.3	1.4	1.6	1.8	2.1	2.3	2.6	2.8	3.1	3.4	3.7	4

table 1- Minimum room area (m²)

Maintenance notes

- Check whether the maintenance area or the room area meet the requirement of the nameplate.
 - It's only allowed to be operated in the rooms that meet the requirement of the nameplate.
- Check whether the maintenance area is well-ventilated.
 - The continuous ventilation status should be kept during the operation process.
- Check whether there is fire source or potential fire source in the maintenance area.
 - The naked flame is prohibited in the maintenance area; and the "no smoking" warning board should be hanged.
- Check whether the appliance mark is in good condition.
 - Replace the vague or damaged warning mark.

Welding

• If you should cut or weld the refrigerant system pipes in the process of maintaining, please follow the steps as below:

Safety operation of flammable refrigerant

- a. Shut down the unit and cut power supply
- b. Eliminate the refrigerant
- c. Vacuuming
- d. Clean it with N2 gas
- e. Cutting or welding
- f. Carry back to the service spot for welding
- The refrigerant should be recycled into the specialized storage tank.
- Make sure that there isn't any naked flame near the outlet of the vacuum pump and it's well-ventilated.


Filling the refrigerant

- Use the refrigerant filling appliances specialized for R32. Make sure that different kinds of refrigerant won't contaminate with each other.
- The refrigerant tank should be kept upright at the time of filling refrigerant.
- Stick the label on the system after filling is finished (or haven't finished).
- Don't overfilling.
- After filling is finished, please do the leakage detection before test running; another time of leak detection should be done when it's removed.

Safety instructions for transportation and storage

- Please use the flammable gas detector to check before unload and open the container.
- No fire source and smoking.
- According to the local rules and laws.

Installation dimension diagram



To ensure safety, please be mindful of the following precautions.

M Warning

- When installing or relocating the unit, be sure to keep the refrigerant circuit free from air or substances other than the specified refrigerant. Any presence of air or other foreign substance in the refrigerant circuit will cause system pressure rise or compressor rupture, resulting in injury.
- When installing or moving this unit, do not charge the refrigerant which is not comply with that on the nameplate or unqualified refrigerant. Otherwise, it may cause abnormal operation, wrong action, mechanical malfunction or even series safety accident.
- When refrigerant needs to be recovered during relocating or repairing the unit, be sure that the unit is running in cooling mode. Then, fully close the valve at high pressure side (liquid valve). About 30-40 seconds later, fully close the valve at low pressure side (gas valve), immediately stop the unit and disconnect power. Please note that the time for refrigerant recovery should not exceed 1 minute.

If refrigerant recovery takes too much time, air may be sucked in and cause pressure rise or compressor rupture, resulting in injury.

- During refrigerant recovery, make sure that liquid valve and gas valve are fully closed and power is disconnected before detaching the connection pipe. If compressor starts running when stop valve is open and connection pipe is not yet connected, air will be sucked in and cause pressure rise or compressor rupture, resulting in injury.
- When installing the unit, make sure that connection pipe is securely connected before the compressor starts running.

If compressor starts running when stop valve is open and connection pipe is not yet connected, air will be sucked in and cause pressure rise or compressor rupture, resulting in injury.

• Prohibit installing the unit at the place where there may be leaked corrosive gas or flammable gas.

If there leaked gas around the unit, it may cause explosion and other accidents.

• Do not use extension cords for electrical connections. If the electric wire is not long enough, please contact a local service center authorized and ask for a proper electric wire.

Poor connections may lead to electric shock or fire.

• Use the specified types of wires for electrical connections between the indoor and outdoor units. Firmly clamp the wires so that their terminals receive no external stresses.

Electric wires with insufficient capacity, wrong wire connections and insecure wire terminals may cause electric shock or fire.

Tools for installation

2 Screw d	river	3 Impact drill	
5 Pipe exp	bander	6 Torque wrench	
8 Pipe cutter 9 Leakage detect			
11 Pressu	re meter 12 Universal meter		
anner	14 Measuring tape		
	5 Pipe exp 8 Pipe cut 11 Pressu	11 Pressure meter	

• Please contact the local agent for installation.

• Don't use unqualified power cord.

Selection of installation location

Basic requirement

Note:

Installing the unit in the following places maycause malfunction. If it is unavoidable, please consult the localdealer:

- 1. The place with strong heat sources, vapors, flammableor explosive gas, or volatile objects spread in the air.
- 2. The place with high-frequency devices (such as welding machine, medical equipment).
- 3. The place near coast area.
- 4. The place with oil or fumes in the air.
- 5. The place with sulfureted gas.
- 6. Other places with special circumstances.
- 7. The appliance shall not be installed in the laundry.

Outdoor unit

- 1. Select a location where the noise and outflow air emitted by the outdoor unit will not affect neighborhood.
- 2. The location should be well ventilated and dry, in which the outdoor unit won't be exposed directly to sunlight or strong wind.
- 3. The location should be able to withstand the weight of outdoor unit.
- 4. Make sure that the installation follows the requirement of installation dimension diagram.
- 5. Select a location which is out of reach for children and far away from animals or plants. If it is unavoidable, please add the fence for safety purpose.

Requirements for electric connection

Safety precaution

- 1. Must follow the electric safety regulations when installing the unit.
- 2. According to the local safety regulations, use qualified power supply circuit and air switch.
- 3. Make sure the power supply matches with the requirement of air conditioner. Unstable power supply or incorrect wiring or malfunction. Please install proper power supply cables before using the air conditioner.
- 4. Properly connect the live wire, neutral wire and grounding wire of power socket.
- 5. Be sure to cut off the power supply before proceeding any work related to electricity and safety. For models with a power plug, make sure the plug is within reach after installation.
- 6. Do not put through the power before finishing installation.
- 7. If the supply cord is damaged, it must be replaced by the manufacturer, its service agent or similarly qualified persons in order to avoid a hazard.
- 8. The temperature of refrigerant circuit will be high, please keep the interconnection cable away from the copper tube.
- 9. The appliance shall be installed in accordance with national wiring regulations.
- 10. Appliance shall be installed, operated and stored in a room with a floor area larger than "X"m² (see table 1).



Please notice that the unit is filled with flammable gas R32. Inappropriate treatment of the unit involves the risk of severe damages of people and material. Details to this refrigerant are found in chapter "refrigerant".

Grounding requirement

- 1. The air conditioner is the first class electric appliance. It must be properly grounding with specialized grounding device by a professional. Please make sure it is always grounded effectively, otherwise it may cause electric shock.
- 2. The yellow-green wire in air conditioner is grounding wire, which can't be used for other purposes.
- 3. The grounding resistance should comply with national electric safety regulations.
- 4. The appliance must be positioned so that the plug is accessible.
- 5. An all-pole disconnection switch having a contact separation of at least 3mm in all poles should be connected in fixed wiring.
- 6. Including an air switch with suitable capacity, please note the following table. Air switch should be included magnet buckle and heating buckle function, it can protect the circuit-short and overload. (Caution: please do not use the fuse only for protect the circuit)

for protect the circuit) Air

Air-conditioner	Air switch capacity
09K、12K	10A
18K	16A
24K	25A

13


Installation of outdoor unit

Step one: fix the support of outdoor unit (select it according to the actual installation situation)

- 1. Select installation location according to the house structure.
- 2. Fix the support of outdoor unit on the selected location with expansion screws.

Note:


- Take sufficient protective measures when installing the outdoor unit.
- Make sure the support can withstand at least four times of the unit weight.
- The outdoor unit should be installed at least 3cm above the floor in order to install drain joint.
- For the unit with cooling capacity of 2300W ~5000W, 6 expansion screws are needed; for the unit with cooling capacity of 6000W ~8000W, 8 expansion screws are needed; for the unit with cooling capacity of 10000W ~16000W, 10 expansion screws are needed.



at least 3cm above the floor


Step two: install drain joint (Only for cooling and heating unit)

- 1. Connect the outdoor drain joint into the hole on the chassis, as shown in the picture below.
- 2. Connect the drain hose into the drain vent.



Step three: fix outdoor unit

- 1. Place the outdoor unit on the support.
- 2. Fix the foot holes of outdoor unit with bolts.




Installation of outdoor unit


Step four: connect indoor and outdoor pipes

I


1. Remove the screw on the right handle of outdoor unit and then remove the handle.



Remove the screw cap of valve and aim the pipe joint at the bellmouth of pipe.



3. Pretightening the union nut with hand.




4. Tighten the union nut with torque wrench by referring to the sheet below.

Hex nut diameter	Tightening torque (N⋅m)
Φ6	15~20
Φ 9.52	30~40
Φ 12	45~55
Φ 16	60~65
Φ 19	70~75

Step five: connect outdoor electric wire

1. Remove the wire clip; connect the power connection wire and signal control wire (only for cooling and heating unit) to the wiring terminal according to the color; fix them with screws.



15

Note: the wiring board is for reference only, please refer to the actual one

Installation of outdoor unit


2. Fix the power connection wire and signal control wire with wire clip (only for cooling and heating unit).

Note:

- After tighten the screw, pull the power cord slightly to check if it is firm.
- Never cut the power connection wire to prolong or shorten the distance.

Step six: neaten the pipes

- 1. The pipes should be placed along the wall, bent reasonably and hidden possibly. Min. semidiameter of bending the pipe is 10cm.
- If the outdoor unit is higher than the wall hole, you must set a U-shaped curve in the pipe before pipe goes into the room, in order to prevent rain from getting into the room.




Note:


• The through-wal height of drain hose shouldn't be higher than the outlet pipe hole of indoor unit.



• The water outlet can't be placed in water in order to drain smoothly.




 Slant the drain hose slightly downwards. The drain hose can't be curved, raised and fluctuant, etc.



Vacuum pumping

Use vacuum pump

- Remove the valve caps on the liquid valve and gas valve and the nut of refrigerant charging vent.
- 2. Connect the charging hose of piezometer to the refrigerant charging vent of gas valve and then connect the other charging hose to the vacuum pump.
- 3. Open the piezometer completely and operate for 10-15min to check if the pressure of piezometer remains in -0.1MPa.
- Close the vacuum pump and maintain this status for 1-2min to check if the pressure of piezometer remains



in -0.1MPa. If the pressure decreases, there may be leakage.

- 5. Remove the piezometer, open the valve core of liquid valve and gas valve completely with inner hexagon spanner.
- 6. Tighten the screw caps of valves and refrigerant charging vent.

Leakage detection

1. With leakage detector:

Check if there is leakage with leakage detector.

2. With soap water:

If leakage detector is not available, please use soap water for leakage detection. Apply soap water at the suspected position and keep the soap water for more than 3min. If there are air bubbles coming out of this position, there's a leakage.

Check after installation

• Check according to the following requirement after finishing installation.

Items to be checked	Possible malfunction
Has the unit been installed firmly?	The unit may drop, shake or emit noise.
Have you done the refrigerant leakage test?	It may cause insufficient cooling (heating) capacity.
Is heat insulation of pipeline sufficient?	It may cause condensation and water dripping.
Is water drained well?	It may cause condensation and water dripping.
Is the voltage of power supply accord- ing to the voltage marked on the nameplate?	It may cause malfunction or damaging the parts.
Is electric wiring and pipeline installed correctly?	It may cause malfunction or damaging the parts.
Is the unit grounded securely?	It may cause electric leakage.
Does the power cord follow the speci- fication?	It may cause malfunction or damaging the parts.
Is there any obstruction in the air inlet and outlet?	It may cause insufficient cooling (heating) capacity.
The dust and sundries caused during installation are removed?	It may cause malfunction or damaging the parts.
The gas valve and liquid valve of connection pipe are open completely?	It may cause insufficient cooling (heating) capacity.
Is the inlet and outlet of piping hole been covered?	It may cause insufficient cooling (heating) capacity or waster eletricity.

Test operation

1. Preparation of test operation

- The client approves the air conditioner.
- Specify the important notes for air conditioner to the client.

2. Method of test operation

- Put through the power, press ON/OFF button on the remote controller to start operation.
- Press MODE button to select AUTO, COOL, DRY, FAN and HEAT to check whether the operation is normal or not.
- If the ambient temperature is lower than 16° C , the air conditioner can't start cooling.

Configuration of connection pipe

Sheet 1 Max length of connection nine

- 1. Standard length of connection pipe
 - 5m, 7.5m, 8m
- Min length of connection pipe For the unit with standard connection pipe of 5m, there is no limitation for the min length of connection pipe. For the unit with standard connection pipe of 7.5m and 8m, the min length of connection pipe is 3m.

I Init m

3. Max length of connection pipe

Shee	et 1 Max length of conn	ec	cion pipe	Unit: m
capacity	Max length of connection pipe		capacity	Max length of connection pipe
5000Btu/h (1465W)	15		24000Btu/h (7032W)	25
7000Btu/h (2051W)	15		28000Btu/h (8204W)	30
9000Btu/h (2637W)	15		36000Btu/h (10548W)	30
12000Btu/h (3516W)	20		42000Btu/h (12306W)	30
18000Btu/h (5274W)	25		48000Btu/h (14064W)	30

4. The calculation method of additional refrigerant oil and refrigerant charging amount after prolonging connection pipe

After the length of connection pipe is prolonged for 10m at the basis of standard length, you should add 5ml of refrigerant oil for each additional 5m of connection pipe.

The calculation method of additional refrigerant charging amount (on the basis of liquid pipe):

- (1) Additional refrigerant charging amount= prolonged length of liquid pipe × additional refrigerant charging amount per meter
- (2) Basing on the length of standard pipe, add refrigerant according to the requirement as shown in the table. The additional refrigerant charging amount per meter is different according to the diameter of liquid pipe. See Sheet 2.

Diameter of connection pipe mm		Indoor unit throttle	Outdoor unit throttle	
Liquid pipe	Gas pipe	Cooling only, cooling and heating (g / m)	Cooling only (g / m)	cooling and heating (g / m)
Ф6	Φ9.5 or Φ12	16	12	16
Φ6 or Φ9.5	Ф16 or Ф19	40	12	40
Ф12	Ф19 or Ф22.2	80	24	96
Ф16	Φ25.4 or Φ31.8	136	48	96
Ф19	-	200	200	200
Φ22.2	-	280	280	280

Sheet 2. Additional refrigerant charging amount for R32

Note: The additional refrigerant charging amount in Sheet 2 is recommended value, not compulsory.


Pipe expanding method

Note:

Improper pipe expanding is the main cause of refrigerant leakage. Please expand the pipe according to the following steps:

A: Cut the pipe


- Confirm the pipe length according to the distance of indoor unit and outdoor unit.
- Cut the required pipe with pipe cutter.




- B: Remove the burrs
- Remove the burrs with shaper and prevent the burrs from getting into the pipe.



- C: Put on suitable insulating pipe
- D: Put on the union nut
- Remove the union nut on the indoor connection pipe and outdoor valve; install the union nut on the pipe.



- E: Expand the port
- Expand the port with expander.




Note:

• "A" is different according to the diameter, please refer to the sheet below:

Outer diameter	A(mm)		
(mm)	Max	Min	
Ф6 - 6.35(1/4")	1.3	0.7	
Ф9.52(3/8")	1.6	1.0	
Ф12-12.7(1/2")	1.8	1.0	
Ф15.8-16(5/8")	2.4	2.2	

- F: Inspection
- Check the quality of expanding port. If there is any blemish, expand the port again according to the steps above.







21

Outdoor Unit


ASH-09BIF/O





These circuit diagrams are subject to change without notice, please refer to the one supplied with the unit.

ASH-18BIF/O ASH-24BIF/O



These circuit diagrams are subject to change without notice, please refer to the one supplied with the unit.

SPLIT AIR CONDI	
INDOOR UN	IT
Model	ASH-09BIF
Rated Voltage	220-240V~
Rated Frequency	50Hz
Cooling Capacity	2600W
Heating Capacity	2800W
Air Flow Volume	560m ³ /h
Sound Pressure Level(H)	36dB(A)
Weight	9kg
Manufactured Date	-
sinclai	R [®]
Producer: SINCLAIR CORPORATION Ltd, 1- Representative: SINCLAIR EUROPE spol. sr.a Purkynova 45, 612 00 Brno, C2).,
	229983532

S	sinc		
		ER OUTDOOR UNI'	Г
Model			<u>I-09BIF</u>
Rated Voltage 22	0-240V~	Cooling Capacity	2600W
Rated Frequency	50Hz	Heating Capacity	2800W
Climate Type	T1	Cooling Power Input	805W
Weight	29.5kg	Heating Power Input	755W
Isolation	Ĩ	Cooling Rated Input	1400W
Refrigerant	R32	Heating Rated Input	1500W
Refri. Charge	0.60kg	Sound Pressure Level	52dB(A)
GWP	675	CO2 equivalent 0.4	1tonnes
Moisture Protection			IPX4
Maximum Allo			4.3MPa
Operating Press			4.3MPa
Operating Press	ire for th	e Suction Side	2.5MPa
Contains fluorinated g	reenhouse ga	ises	
Producer: SINCLAIR CO	DRPORATIO	N Ltd, 1-4 Argyll St., London, Ul spol. s r.o., Purkynova 45, 612 00	K Brno, CZ
	Λ		
	10	6322998353	2

SPLIT AIR CONDI	TIONER			
INDOOR UNIT				
Model	ASH-13BIF			
Rated Voltage	220-240V~			
Rated Frequency	50Hz			
Cooling Capacity	3500W			
Heating Capacity	3670W			
Air Flow Volume	680m ³ /h			
Sound Pressure Level(H)	38dB(A)			
Weight	10.5kg			
Manufactured Date	0			
sincla				
Producer: SINCLAIR CORPORATION Ltd, 1- Representative: SINCLAIR EUROPE spol. s r. Purkynova 45, 612 00 Brno, C.	0.,			
	229983534			


		Lair	
	DITION	ER OUTDOOR UNI	-
Model			I-13BIF
Rated Voltage 22	0-240V~	Cooling Capacity	3500W
Rated Frequency	50Hz	Heating Capacity	3670W
Climate Type	T1	Cooling Power Input	1085W
Weight	31kg	Heating Power Input	990W
Isolation	I	Cooling Rated Input	1400W
Refrigerant	R32	Heating Rated Input	1500W
Refri. Charge		Sound Pressure Level	53dB(A)
GWP	675	CO2 equivalent 0.4	7tonnes
Moisture Protection			IPX4
Maximum Allow			4.3MPa
Operating Pressu			4.3MPa
Operating Pressu	re for th	e Suction Side	2.5MPa
Manufactured Date			
Contains fluorinated g	reenhouse ga	ises	_
Producer: SINCLAIR CO Representative: SINCLA	RPORATIO	N Ltd, 1-4 Argyll St., London, UF spol. s r.o., Purkynova 45, 612 00	Brno. CZ
itepresentation of on (CE)	^		
	$-\Lambda$		
	13		
		6322998353	5


SPLIT AIR CONDI	TIONER			
INDOOR UNIT				
Model	ASH-18BIF			
Rated Voltage	220-240V~			
Rated Frequency	50Hz			
Cooling Capacity	5130W			
Heating Capacity	5280W			
Air Flow Volume	850m ³ /h			
Sound Pressure Level(H)	44dB(A)			
Weight	13.5kg			
Manufactured Date	0			
sinclai	D ®			
Producer: SINCLAIR CORPORATION Ltd, 1- Representative: SINCLAIR EUROPE spol. sr.c Purkynova 45, 612 00 Brno, C2	.,			
/ () (€ 🕅				
	29983536			


sinclai	R [®] AIR CO	ONDITIONER OUTD	OOR UNIT
Model	ASH-18BIF		
Rated Voltage	220-240V~	Cooling Capacity	5130W
Rated Frequency	50Hz	Heating Capacity	5280W
Climate Type	T1	Cooling Power Input	1580W
Weight	39kg	Heating Power Input	1420W
Isolation	Ι	Cooling Rated Input	2100W
Refrigerant	R32	Heating Rated Input	2300W
Refri. Charge	0.90kg	CO ₂ equivalent	0.61tonnes
GWP	675	Sound Pressure Level	56dB(A)
Maximum Allow	able Pressu	re	4.3MPa
Operating Pressu	ıre (Dischar	ge Side/Suction Side)	4.3/2.5MPa
Manufactured Date	2017.01	Moisture Protection	IPX4
Contains Producer: SIN Representative	fluorinated gi CLAIR CORPORAT : SINCLAIR EUROJ	reenhouse gases ION Ltd, 1-4 Argyll St., London, UK PE spol. s r.o., Purkynova 45, 612 00 Bi	rno, CZ


SPLIT AIR COND	ITIONER
INDOOR UN	IT
Model	ASH-24BIF
Rated Voltage	220-240V~
Rated Frequency	50Hz
Cooling Capacity	6450W
Heating Capacity	6450W
Air Flow Volume	1250m ³ /h
Sound Pressure Level(H)	44dB(A)
Weight	16.5kg
Manufactured Date	
sincla	IR ®
Producer: SINCLAIR CORPORATION Ltd, 1- Representative: SINCLAIR EUROPE spol. s r. Purkynova 45, 612 00 Brno, C.	0.,
	229983538

Model		ASH-24BIF	
Rated Voltage	220-240V~	Cooling Capacity	6450W
Rated Frequency	50Hz	Heating Capacity	6450W
Climate Type	T1	Cooling Power Input	1950W
Weight	52.5kg	Heating Power Input	1735W
Isolation	Ι	Cooling Rated Input	3000W
Refrigerant	R32	Heating Rated Input	3100W
Refri. Charge	1.70kg	CO ₂ equivalent	1.15tonnes
GWP	675	Sound Pressure Level	58dB(A)
Maximum Allov	able Pressu	re	4.3MPa
Operating Press	ıre (Dischar	ge Side/Suction Side)	4.3/2.5MPa
Manufactured Date	2017.01	Moisture Protection	IPX4
Producer: SINCL	AIR CORPORATION	e nhouse gases v Ltd, 1-4 Argyll St., London, UK pol. s r.o., Purkynova 45, 612 00 Brno, u 1111 1111	









NOTE CONCERNING PROTECTION OF ENVIRONMENT



This product must not be disposed of via normal household waste after its service life, but must be taken to a collection station for the recycling of electrical and electronic devices. The symbol on the product, the operating instructions or the packaging indicate such disposal procedures. The materials are recyclable in accordance with their respective symbols. By means of re-use, material recycling or any other form of recycling old appliances you are making an important contribution to the protection of our environment. Please ask your local council where your nearest disposal station is located.

INFORMATION CONCERNING USED REFRIGERANT MEDIUM

This unit is containing fluorinated gases included in the Kyoto protocol. The maintenance and the liquidation must be carried out by qualified personnel. Type of refrigerant: R32

The quantity of the refrigerant: please see the unit label. The value GWP: 675 (1 kg R32 = $0,675 \text{ t CO}_2 \text{ eq}$) GWP = Global Warming Potential



Appliance filled with flammable gas R32.

In case of quality problem or other please contact your local supplier or authorized service center. **Emergency number: 112**

PRODUCER

SINCLAIR CORPORATION Ltd. 1-4 Argyll St. London W1F 7LD Great Britain

www.sinclair-world.com

This product was manufactured in China (Made in China).

REPRESENTATIVE

SINCLAIR EUROPE spol. s r.o. Purkynova 45 612 00 Brno Czech Republic

TECHNICAL SUPPORT

NEPA spol. s r.o. Purkynova 45 612 00 Brno Czech Republic

Tel.: +420 800 100 285 Fax: +420 541 590 124

www.sinclair-solutions.com info@sinclair-solutions.com