

OPTIONAL ACCESSORIES

SCMI-01 SINCLAIR COMMUNICATION MODULE

The module is designed for applications requiring source of coldness or heat, such as cooling for air-conditioning systems or heating with connected hydro box. The SCMI-01 control module is designed for controlling ASGE-xxAIN WK and ASGE-xxAIN-3 WK outdoor inverter units. This module can operate in 3 modes: the slave unit (control by 0-10V), the autonomous pressure (evaporation temperature) control mode and the autonomous temperature control mode for cooling or heating.

Power indicator and optional and three yellow LEDs indicate switching of the module relays.



SDM-01



FMD-01



SND-01



SWC-02

FMD-01 FAN MOTOR CONTROL MODULE

This fan module FMD-01 can control fan motor of NEW UNI DC INVERTER SERIES indoor units (ASF-xxAIN, ASC-xxAIN, ASD-xxAIN).

SDM-01 DOOR MODULE

Door module is used to control NEW UNI DC INVERTER outdoor units ASGE-XXAIN WK and ASGE-XXAIN-3 WK.

SND-01 DISPLAY BOARD

Using wall-mounted display, you can control duct units ASD-xxAIN. It indicates set operation mode and set temperature. It enables switching the unit into automatic cooling or heating mode and displaying error code (report). It works as remote controller signal receiver too.

SWC-02 WIRED CONTROLLER

This optional wired controller can be connect by 2line wire right to indoor units from FOCUS series an split CONSOLE series. Week timer, daily timer, two weeks program, function lock and buttons lock is standard.



Note: It cannot be used on wall mounted and console type indoor unit.



SCC-16 CENTRALIZED CONTROL AND WEEKLY TIMER

The centralized controller allows you to centralize up to 16 units at the same time and provide weekly start stop times.

Via a telephone network and p.c. you can also monitor the installed system.

The central controller can be used for the units which are equipped with the wire controller.



G2S MODULE

It is used for controlling SINCLAIR air-conditioners by means of your mobile phone. It applies IR transfer for communication with the air-conditioner, therefore there is no need to connect it to the air-conditioner whatsoever. In this view, it operates as another remote controller. The module is equipped with two transmitting IR diodes, signaling diodes, slot for inserting SIM card and with connectors for connecting power supply cable and for connecting to the USB port of a computer.

SPB-01, SPB-02 PORT BOARD

It is possible to connect this optional accessories with contacts to a display of indoor unit from KITE series. This module contains contacts for distant control of the unit (on/off contact), for error signaling and for wire controllers KJR-120G (with SPB-01) and for central controller CCM (with SPB-02).

SWM-01, SWM-02 WIFI MODULE

WiFi modules can be connected to indoor units to achieve long distance control with smart phone or tablet. SWM-01 for Kite series, SWM-02 for Console split units